

The pool light is designed for above ground vinyl and steel walled pools. The light contains an internal magnet that easily attaches to a steel walled pool. A metal plate is also included to attach to a soft side pool.

WARNING: Contains strong magnets. Keep light away from young children, mobile phones, magnetic media such as hard drives and other electronic devices.

IMPORTANT: This product is for use with above ground pool walls with a maximum thickness of .5 mm (0.02 in), or rigid steel walls. Not for use with in ground pools.

Pool Light Battery Installation

NOTE: Always make sure the product is thoroughly dry before inserting batteries.

1. Turn the back cover counter clockwise to open.
2. Insert (3) AAA batteries with correct polarity (+,-) following the illustration inside the battery compartment
3. Replace the back cover, turning clockwise until snug. Be sure the gasket is clean and properly seated.

WARNING: Ensure that all threads are engaged and cover is fully and evenly seated onto gasket before submerging. Failure to properly seal unit will cause leaks, damaging the product and voiding the warranty.

On/Off Button Operation

On/off button is at center of light (blue button).

1. Press button once to turn on.
2. Press again to shut off.

NOTE: Light will shut off automatically after 2 hours.

Pool Installation

The pool light can be attached to any location and is easily moved to different areas of the pool. After the batteries are installed, simply place the blue metal plate on the outside of the pool wall and the pool light on the inside of the pool wall. Ensure the plate is properly aligned with the internal magnet (in the center of the pool light).

Remote Control (battery comes pre-installed)

WARNING: The remote control is not waterproof.

Do not submerge.

Pull plastic tab to engage battery. The operating range for the remote is 3 to 6 feet (1 to 2 meters) when the pool light is submerged in up to 2 feet (0.6 meters) of water.

For Best Results Using the Remote: The remote sensor on the pool light should be at the top of the light when placed in water.

Remote Function

ON	Turns light on
OFF	Turns light off
Flash	Flashing white lights
Strobe	Flashing rotating thru all colors
Fade	Fade from one color to the next
Smooth	Flashing alternating red, blue and green
Brightness	Increase or decrease brightness (single colors only)
Color Selection	Use the color buttons to select a single color including White (W), Red (R), Green (G) and Blue (B)

Storage

Thoroughly air-dry all pieces prior to storage. If the product is not going to be used for longer than one month, remove the batteries to prevent discharge and corrosion.


WARNING: SEIZURES - PEOPLE WITH PHOTOSENSITIVE EPILEPSY CAN HAVE SEIZURES TRIGGERED BY FLICKERING OR FLASHING LIGHTS SUCH AS STROBE OR DISCO LIGHTS.

Do Not Return Product to Store Please feel free to contact us with any questions. For ALL warranty inquiries, please contact GAME customer service at 1.888.339.2546 ext 135.

GAME warrants that the product will be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of purchase.

Requires three (3) AAA batteries (not included)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



Great American Merchandise & Events™ (GAME™)
Scottsdale, AZ 85260 USA
888.339.2546

www.game-group.com
Designed in the USA. Made in China.
© 2015 GAME. All rights reserved.



4306

